


Touchscreen driver installation procedure for CF-VDL02


<CF-M34 Series>

The touchscreen driver has been installed. You can use the touchscreen without changing the settings when the LCD Monitor is connected to Serial Port B. To connect to Serial Port A, change the settings using the following procedure.


Windows 2000

- 1 Select  from the taskbar or select [Settings] from [Start] - [Programs] - [UPDD].
- 2 Select [Hardware] and set [Settings For] to [Device 2] and [COM port] to [COM 1].


Windows XP

- 1 Select  from the taskbar or select [Settings] from [Start] - [All Programs] - [UPDD].
- 2 Select [Hardware] and set [Settings For] to [Device 2] and [COM port] to [COM 1].

Windows 98

- 1 Select  from the taskbar or select [Settings] from [Start] - [Programs] - [UPDD].
- 2 Select [Hardware] and set [Settings For] to [Device 2] and [COM port] to [COM 1].

Windows NT

- 1 Select  from the taskbar or select [Settings] from [Start] - [Programs] - [UPDD].
- 2 Select [Hardware] and set [Settings For] to [Device 2] and [COM port] to [COM 1].

<Other models>

Windows 2000

- 1 Prepare the CD drive following the Reference Manual of the computer and set the driver CD-ROM to the CD drive.
- 2 Set the display destination to the LCD Monitor by **(Fn) + (F3)**, and set the display resolution to 1024 x 768 at [Start] - [Settings] - [Control Panel] - [Display] - [Settings].
- 3 In [Start]-[Run], input "D:\xp2k98\Setup.exe" and select [OK].
(“D” is the drive letter of the CD drive. You can change the letter to suit your preference.)
- 4 Select [Next] at “Welcome”.
- 5 Select [Accept] at “License Agreement”.
- 6 Select [Next] at “Folder”.
- 7 Select [Next] at “Directory”.
- 8 Select [Next] at “Install System Tray Icons”.
- 9 At “Number of devices”, input “1” and select [Next].
- 10 Select [Next] at “Desktop segment”.
- 11 Select [Next] at “Select controller”.
- 12 At “Port”, select COM number of serial port that is connected to the LCD Monitor and select [Next].
- 13 Select [Next] at "Ready to install".
- 14 Calibrate the touchscreen.
Point “X” or “↑” mark by the following the message on the display.
- 15 Select [Finish] at “Setup”.

Windows XP

- 1 Prepare the CD drive following the Reference Manual of the computer and set the driver CD-ROM to the CD drive.
- 2 Set the display destination to the LCD Monitor by **(Fn) + (F3)**, and set the display resolution to 1024 x 768 at [Start] - [Control Panel] - [Performance and Maintenance] - [Display] - [Settings].
- 3 In [Start]-[Run], input "D:\xp2k98\Setup.exe" and select [OK].
(“D” is the drive letter of the CD drive. You can change the letter to suit your preference.)
- 4 Select [Next] at “Welcome”.
- 5 Select [Accept] at “License Agreement”.
- 6 Select [Next] at “Folder”.
- 7 Select [Next] at “Directory”.
- 8 Select [Next] at “Install System Tray Icons”.

- 9 At "Number of devices", input "1" and select [Next].
- 10 Select [Next] at "Desktop segment".
- 11 Select [Next] at "Select controller".
- 12 At "Port", select COM number of serial port that is connected to the LCD Monitor and select [Next].
- 13 Select [Next] at "Ready to install".
- 14 Calibrate the touchscreen.
Point "X" or "⬆" mark by the following the message on the display.
- 15 Select [Finish] at "Setup".

Windows 98

- 1 Prepare the CD drive following the Reference Manual of the computer and set the driver CD-ROM to the CD drive.
- 2 Set the display destination to the LCD Monitor by **(Fn) + (F3)**, and set the display resolution to 1024 x 768 at [Start] - [Settings] - [Control Panel] - [Display] - [Settings].
- 3 In [Start]-[Run], input "D:\xp2k98\Setup.exe" and select [OK].
(“D” is the drive letter of the CD drive. You can change the letter to suit your preference.)
- 4 Select [Next] at "Welcome".
- 5 Select [Accept] at "License Agreement".
- 6 Select [Next] at "Folder".
- 7 Select [Next] at "Directory".
- 8 Select [Next] at "Install System Tray Icons".
- 9 At "Number of devices", input "1" and select [Next].
- 10 Select [Next] at "Desktop segment".
- 11 Select [Next] at "Select controller".
- 12 At "Port", select COM number of serial port that is connected to the LCD Monitor and select [Next].
- 13 Select [Next] at "Ready to install".
- 14 Calibrate the touchscreen.
Point "X" or "⬆" mark by the following the message on the display.
- 15 Select [Finish] at "Setup".

Windows NT

- 1 Prepare the CD drive following the Reference Manual of the computer and set the driver CD-ROM to the CD drive.
- 2 Set the display destination to the LCD Monitor by **(Fn) + (F3)**, and set the display resolution to 1024 x 768 at [Start] - [Settings] - [Control Panel] - [Display] - [Settings].
- 3 In [Start]-[Run], input "D:\Nt\Setup.exe" and select [OK].
(“D” is the drive letter of the CD drive. You can change the letter to suit your preference.)
- 4 Select [Next] at "Welcome".
- 5 Select [Accept] at "License Agreement".
- 6 Select [Next] at "Folder".
- 7 Select [Next] at "Directory".
- 8 Select [Next] at "Install System Tray Icons".
- 9 At "Number of devices", input "1" and select [Next].
- 10 At "Port", select COM number of serial port that is connected to the LCD Monitor and select [Next].
- 11 Select [Next] at "Ready to install".
- 12 Select [Finish] at "Complete".
- 13 Select [Yes] to reboot the computer.
- 14 Log on the computer and calibrate the touchscreen.
Point "X" mark by the following the message on the display.